

OPERATING INSTRUCTIONS LP A2 SERIES

INDEX

- 1. General Infrormations
- 2. Product Features
- 3. Purpose of Using Product
- 4. Product Error
- 5. Product Care and Clearance
- 6. Product Montage and Removing
- 7. Product Returning and Disposal



1. General Informations

The pressure switch described in the operating instructions has been designed and manufactured using state of-the-art technology.

All components are subject to stringent quality and environmental criteria during manufacturing.

Our quality management systems are certified to ISO 9001: 2015

Pressure switches are not safety equipment of system.

Operating instruction is part of product and it must be reachable conviniently Personal who is using pressure switch, must read and understand precisionly. User is responsible about all safety applications.

User must be sure about comply with purpose of pressure switch.

User must be sure about any destruction on pressure switch while on transport before montage.

PNOMEK® is not responsible about problems caused by incorrect installation.

Values on product defining plate are maximum values and all of them can not be used at the same time.


If you need to use pressure switch in agressive chemicals, please contact with PNOMEK[®].

It is advised absolutely that strict to Hydraulic oil (liquid) clearance standarts. You must use filteration for preventing system errors. It is effective about long system life.

You must avoid from using under shock pressure and out of indicated values for having long life working service.



2. Product Features



- 1. Pressure Setting Knop
- 2. Pressure Setting Scale
- 3. Contra-nut
- 4. Product Defining Plate
- 5. Electrical Connection Socket
- 6. Body
- Process connection
 A-A

Product Features and Function


- 1-) Pressure Setting Knop: Working pressure is set with pressure setting knop on pressure switch. Whern you turn to clockwise, working pressure rises. When you turn to counter-clockwise, working pressure drops.
- 2-) Pressure Setting Scale: It is used as reference while working pressure set.
- 3-) Contra Nut: It gives convinient of panel type montage to pressure switch.
- 4-) Product Defining Plate: It includes mechanic and electrical informations. Please contact with us If you need information out of parameters on defining plate.
- 5-) Electrical Connection Socket: It is product of electrical connection part. Please contact with us If you need information out of parameters on defining plate
- 6-) Body: Body, component of pressure switch, has sensitive dimension. You must not install pressure switch, keeping body.
- 7-) 22 A-A: You must install pressure, keeping 22 A-A



3. Purpose of Using

- 1. LP A3 Series pressure switch opens or closes electric circuit depending on pressure rising or dropping.
- 2. Usage of pressure switch must comply with technic specification
- 3. Pressure switch has been designed for complied with purposed usage. It must be used as indicated here.
- 4. User must be sure about comply with purpose of pressure switch.
- 5. If you need to use pressure switch in agressive chemicals, please contact with PNOMFK®.
- 6. PNOMEK® is not responsible about using out of operating insturction

Product Defining Plate



- 1. Product Code
- 2. Working Pressure
- 3. Output Signal
- 4. Output point
- 5. Pmax. value
- 6. Contact Connection



4. Errors







WARNING!!

Risk of injury, property damage and environmental damage; If you can not prevent errors although actions, pressure switch must be taken from usage.

- You check the pressure and protect safety in case of pressure switch Works accidentally.
- Connect with manufacturer.
- If you need to return the pressure switch, you must review product returning part.

WARNINGI!

Risk of injury due to dangerous material, property damage and environmental damage;

If there is any connection with dangerous material (Example. oxygen, acetylen, burner or poisoner materials), harmful materials (Example. corrosion, poisoned, cancinogenic, radioactive), cooling systems and compressors physical injuries, property damages and environmental damages can be occur.

- If any error occurs, product might has extreme heat, and corrosion material under high pressure or vacuum.
- Complied current codes as well standart arrangement for these materials or arrangement must be followed.
- You must wear necessary equipment clothes.

Look back page of operating insturction of contact informations.

| Errors | Reasons | Caution |
|-----------------------------------|----------------------------|-----------------------------|
| No Output Signal | Disconnection between | Control the complete |
| | cables | circuit |
| Different zero point signal | Working pressure limit has | Comply with permissible |
| | been exceeded | extreme pressure limit |
| | | |
| Different zero point signal | Working tempurature | Comply with permissible |
| | high/low | tempurature |
| Different pressure changes, fixed | Mechanic extreme load due | Change the product. If |
| output signal | to extreme pressure | there is any problem still, |
| | | contact wit manufacturer. |
| Signal range different/fault | Working tempurature is | Comply with permissible |
| | extremly hot/cold | tempurature |
| Signal range is dropping/rising | Mechanic extreme load due | Change the product. If |
| | to extreme pressure | there is any problem still, |
| | | contact wit manufacturer. |



5. Product Care and Clearance

Product Care

Pressure switch has not a necessary about care.

Pressure switch repairing is made by only manufacturers

Product Clearance

Pressure switches clearances is must be watchfully. Clearance must occur without any destruction on product or product defining plate.

Uncomplied clearance materials for pressure switch, corrosion clearance materials or sharpened materials can destruct the product. Please avoid from using these materials

You must use a soft and wet cloth for clearance of product.

6. Product Montage and Removing

Product Montage

- 1. Clearing the connection
- 2. Screw the product manual to connection place.
- 3. Screw the product with flathead screw driver.
- 4. Make electrical connection.

Removing Product

- 1. Deactive the pressure of product.
- 2. Disconnect the electrical connection.
- 3. Remove the product with flathead screw driver.



7. Product Returning and Disposal

Product Returning

While you are sending the product, you must be careful about followings: If products that returning to PNOMEK, has dangerous chemical materials, It must be cleared before returnin operation. Product absolutely must not have any dangerous chemical materials.

While you return the product, product must be in original box, original ambalage or appropriate ambalage.

Product Disposal

False product disposal may have a risk. While you destruct the product, please comply with environment and special waste disposal rules

